

I-protect Lifeclean - 5 l (BE-REG-00052)

GENERAL



Concentrated chlorine dioxide cleaning agent and disinfectant with bactericidal, virucidal, sporicidal and fungicidal action.

- Suitable for all water-resistant surfaces
- Effectively cleans and disinfects in just 2 minutes
- CLP-free: safe for humans and for the environment
- Prevents the formation of biofilms with repeated use
- Reduces unpleasant odours
- 100% effective, without the risk of developing antimicrobial resistance



BE: BE-REG-00052 (open circuit), FR: 67783, LU: 137/20/L

Lifeclean complies with the European EN standards and has undergone clinical testing performed by external institutions and laboratories.



pH 2

USAGE

Use biocides with caution. Before using, read the label and the product information.

First, remove any visible dirt from the surfaces and materials to be disinfected. Apply Lifeclean using a clean cloth or a spray bottle. Ensure that the surface is covered with a sufficient quantity of Lifeclean and allow to work for 2 minutes. Do not rinse off; allow to air-dry. On metal surfaces, wiping/rinsing off after the contact time is recommended due to the low pH value.

1 litre of Lifeclean can disinfect a surface area of approximately 25 m².

Only use this product for its specified purposes. If in doubt, first test the product in an inconspicuous area. BOMA is not responsible for any damages if the product is used incorrectly. Consult the Safety Data Sheet (SDS) for additional information.



+ 20% LIFECLEAN
DISINFECTANT



2 MIN.

I-protect Lifeclean - 5 I (BE-REG-00052)

TECHNICAL SPECIFICATIONS

Dimensions product (WxHxD) 13.02 x 29 x 19.55 cm

Spores

EN 13697:2001 (2 min): Bacillus subtilis ATCC 6633; Clostridium difficile UK 027
EN 13704:2002 (2 min): Clostridium difficile UK 023; (5-10 min) Clostridium difficile UK 027
EN 17126:2018 (2-5 min): Bacillus subtilis; Bacillus cereus; Clostridium difficile

Mycobacteria

EN 14348:2005 + EN 14563:2009 (1 min): Mycobacterium terrae ATCC 15755; Mycobacterium avium ATCC 15769

Viruses

EN 14349:2007 (5 min): PPV, strain 893/76
EN 14476:2013 (1 min): Poliovirus Type 1, LSc-2aba; Adenovirus Type 5, strain Adenoid 75, ATCC VR-5; Murine Norovirus Strain S99
EN 14476:2013 + EN A2:2019 (1 min): Feline coronavirus, Strain Munich
EN 14476:2015 (30 sec): Bovine coronavirus (BCoV)
EN 14675:2015 (1 min): Avian influenza virus, (H10N7); (5 min) IPN 107TCID50 Salmonid fish viral infection

Fungi

EN 13624:2013 (1 min): Candida albicans ATCC 10231; Aspergillus brasiliensis ATCC 16404
EN 14562:2006 (1 min): Candida albicans ATCC 10231; (2-5 min) Aspergillus brasiliensis (niger)/black mold ATCC 16404
EN 16615:2015 (2 min): Candida albicans ATCC 10231

Bacteria

EN 13727:2014 (1 min): Pseudomonas aeruginosa ATCC 15442; Staphylococcus aureus ATCC 6538; Enterococcus hirae ATCC 10541
EN 13727:2015 (2 min): Pseudomonas aeruginosa ATCC 15442; Escherichia coli ATCC 25922; Campylobacter jejuni ATCC 33560; Salmonella typhimurium ATCC 14028; Legionella pneumophila ATCC 33152; Klebsiella pneumoniae (ESBL) CCUG 54718; Acinetobacter baumannii (Clinical strain); Staphylococcus aureus ATCC 6538; Enterococcus hirae ATCC 10541; Listeria monocytogenes CCUG 51681; Streptococcus equi CCUG 37782; Enterococcus faecium (VRE) CCUG 56431
EN 14349:2012 (2 min): Aeromonas salmonicida ATCC 14174; Yersinia ruckeri ATCC 29473; Carnobacterium piscicola ATCC 3586
EN 14561:2006 (1 min): Pseudomonas aeruginosa ATCC 15442; Staphylococcus aureus ATCC 6538; Enterococcus hirae ATCC 10541
EN 16615:2015 (2 min): Pseudomonas aeruginosa ATCC 15442; Staphylococcus aureus ATCC 6538; Enterococcus hirae ATCC 10541

LOGISTIC DATA

Product

Article	222145
Unit	Can
Content	5L
Dimensions	19.55 x 29 x 13.02 cm
Gross weight	5200 g
Net weight	5000 g
EAN code	7340112151010

Packing

Quantity per packing	3
Dimensions	39.8 x 30.4 x 20 cm
Gross weight	16000 g

Pallet

Quantity per pallet	144
Layers	4
Units per layer	36

